

PERCEPTION STUDY

PERCEPTION STUDIES

Introduction



Wellbeing_Perception Study

CoeLux® offers a new type of indoor illumination, which perfectly mimics the effects of sun and sky light entering a room on a sunny day.

Relying upon the comments from the several hundreds of people that have visited the first installations, it is evident that CoeLux® is capable of generating a very high living comfort even in fairly small spaces.

In order to provide a scientific support to the above claim, CoeLux® has begun a research investigation aimed at quantifying the positive impact on the wellbeing by means of psychological, physiological, biological and even medical tests.

PERCEPTION STUDIES

Introduction



Wellbeing_Perception Study

In this context, Bartenbach GmbH, which has a long-lasting experience in the field of light perception psychology, has already performed in collaboration with CoeLux® a preliminary study regarding the impact of CoeLux® illumination on people.

To this end a sample of 100 people partecipated in a randomized controlled comparative study, by means of tests delivered both in CoeLux® illuminated room and in a second room identical to the first, but illuminated with top quality state of the art illumination, of similar (average) CCT, luminous flux, spectral quality etc. (hereinafter: «the Best Standard»).

PERCEPTION STUDIES

Perception study aiming to measure the impact of natural light on psyco-physiological paramenters



Perception Study Set Up:

- A sample of 200 persons have been selected with the following characteristics: Age between 18-65 year; 50% female
- Approval by Ethical committee (University of Innsbruck)

• Two identical windowless rooms have been built for the test: one illuminated with CoeLux and the other one with standard Lighting Systems



PERCEIVED AMBIENT QUALITY

POSITIVE ASSOCIATIONS



NEGATIVE ASSOCIATIONS



MULTI-DIMENSIONAL Perception study

PSYCO-PHYSIOLOGICAL PARAMETERS

PERCEIVED MOOD STATE

PERCEIVED ANXIETY

PERCEIVED ROOM ENVIRONMENT

PERCEIVED STRESS STATE

SUSTAINED ATTENTION



Wellbeing_Perception Study

MEASUREMENTS TEST

• Performance-related Activity (25 Items)

- General Well-being (24 Items)
- General Deactivation (32 Items)
- State-Trait Anxiety Inventory (STAI)
 Claustrophobic Symptoms Checklist
- Room Atmosphere Questionnaire (RAQ)
- Perceived Restorativeness Scale (PRS)
- Dundee Stress State Questionnaire (DSSQ):
 - Energetic Arousal Scale
 - Tension Scale

• Acoustic Go-/No Go-Task

>

>

>

>

PERCEIVED MOOD STATE Performance-Related Activity

Measures: 25 items measured, e.g. keen, eager, motivated to work, active, energetic, forthcoming, persistent, concentrated, ...

Rationale: actual mood state at the beginning (Short-term) and at the end of the data collection period (Long-term)

Key findings:

CoeLux® Performance-Related Activity Score is 30% higher than standard





PERCEIVED MOOD STATE General Well-Being

Measures: 24 items measured, e.g. confident, unconcerned, pleased, comfortable, in good spirit, ...

Rationale: actual mood state at the beginning (Short-term) and at the end of the data collection period (Long-term)

Key findings:

CoeLux® General Well-Being is rated 38% higher than standard



Wellbeing_Perception Study



"Report on comfort and wellbeing measurements" by Bartenbach GmbH., Austria pg: 43

PERCEIVED MOOD STATE General Deactivation

Measures: 32 items measured, e.g. careless, spiritless, powerless, lazy, passive, slow, sleepy, demoralized, ...

Rationale: actual mood state at the beginning (Short-term) and at the end of the data collection period (Long-term)

Key findings:

CoeLux® General Deactivation is 36% less strong than standard in short-term and 39% in long-term



Wellbeing_Perception Study



"Report on comfort and wellbeing measurements" by Bartenbach GmbH., Austria pg: 45

PERCEIVED ANXIETY State-Trait Anxiety Inventory (STAI)

Measures: a total anxiety score was derived by adding the ratings (1 to 4) of 20 items, e.g. feel calm, secure, tens, upset, satisfied, frightened, nervous, relaxed, worried, ...

Rationale: room lighting long-term effects on the perceived anxiety state have been measured. A Cut-Point of 40 ** detects clinically significant symptoms for S-Anxiety Scale

Key findings:

Under CoeLux® state anxiety was rated significantly lower than standard. Actually standard lighting crossed the cut-off score of STAI indicating clinically relevant heightened anxiety scores.







F(1, 98)=4.73, p=0.032

"Report on comfort and wellbeing measurements" by Bartenbach GmbH., Austria pg: 49 **"Measure of Anxiety" by Laura J. Julian, PhD, University of California, San Francisco – 2011 November pg. 2

PERCEIVED ANXIETY Claustrophobic Symptoms Checklist

Measures: two out of 6 claustrophobic symptoms were significantly different between the two lighting conditions: item "I feel dizzy" and item "I think that I must leave the room"

Rationale: to quantify potential lighting effects on claustrophobic feelings

Key findings:

The feeling "must leave the room" was rated 28% lower under CoeLux® than standard



F(1, 98)=9.54, p=0.003



PERCEIVED ROOM ENVIRONMENT Perceived Restorativeness Scale | Sub-scale "Fascination"

Measures: 8 items (6 positives, 2 negatives) where scored on 7-point Likert Scale, e.g. "my attention is drawn to many interesting things", "I want to spend more time looking at the surroundings", "the place is boring", "the setting is fascinating", …

Rationale: quantify the impact of room lighting installations on perceived restorative environment

Key findings:

Total score of fascination was significantly higher under CoeLux® than standard lighting



F(1, 98)=8.35, p=0.005



PERCEIVED STRESS STATE Dundee Stress State Questionnaire | Energetic Arousal Scale

Measures: DSSQ test focused on Task Engagement factor - Energetic Arousal subscales (EA; alert - lethargic)

Rationale: DSSQ has been utilized to quantify the impact of different room lighting installations on stress responses in sustained performance. Typically, a decrease in energetic arousal is accompanied by an increase in tense arousal, thus indicating that vigilance is emotionally stressful

Key findings:

The Energetic Arousal Score was 15% higher under CoeLux® than standard



F(1, 73)=6.14, p=0.015





PERCEIVED STRESS STATE Dundee Stress State Questionnaire | Tension Scale

Measures: DSSQ test focused on Distress factor - Tense Arousal subscales (TA; nervous - relaxed)

Rationale: DSSQ has been utilized to quantify the impact of different room lighting installations on stress responses in sustained performance. Typically, a decrease in energetic arousal is accompanied by an increase in tense arousal, thus indicating that vigilance is emotionally stressful

Key findings:

The Tense Arousal Score was 15% lower under CoeLux® than standard



F(1, 98)=13.14, p<0.001



"Report on comfort and wellbeing measurements" by Bartenbach GmbH., Austria pg: 57



SUSTAINED ATTENTION Acoustic Go-/No Go-Task

Measures: 54 pairs of tones, each tone heard for 80ms and the two tones separated by 500ms. The first tone at 1000Hz while second tone was either higher (1100Hz) or lower (900Hz). Whenever the second tone was higher, the test person had to press a button as fast as possible or restrain from a reaction

Rationale: quantify impact of different room lighting on correct reactions in the sustained attention test

Key findings:

The Correct Reactions were <mark>8% higher</mark> under CoeLux® than standard





F(1, 3442)=14.99, p<0.001

