## Beam 4

### **SURFACE MOUNT REGULAR LIT CORNER PATTERNS**



\* Please see page 2 for example on how to specify various right angle patterns.

<b> </b>	11'	<b>→</b>	_  <-		<b>-9'</b>	<del>-</del>
90°	900	8'   	111	) 90°	90°	11'
TB4SLEDPAT	R (11'X8')		TB4SLEDPAT		U (9'X11'X11	')
PRODUCT ID	ODUCT ID PATTERNS AND LENGTH		PRODUCT ID		PATTERNS AND LEN	NGTH
TOP VIEW	- Rectangle Corner Pattern		TOP VIEW	- Open	Shape Corn	er Pattern

Project	
Туре	
Notes	

IMPORTANT! - all corner patterns must be submitted with drawings indicating dimensions and angles degree.

Refer to axislighting.com for complete fixture details, IES files, and installation instructions

#### **Ordering Guide**





TB4SLEDPAT											
PRODUCT ID		PATTERNS AND LENGTH (SELECT ONE)		LUMENS/FT		CRI		COLOUR TEMP.		SHIELDING DIRECT	
TB4SLEDPAT	Beam 3 Surface	S(L)	square shape (length)	400	400 lm/ft - Minimum	80	80 CRI	30	3000 K	so	spotless lens
		R(LxL)	rectangular shape (length)	1000	1000 lm/ft - max for			35	3500 K	ASO	Asymmetric
		U(LxLxL)	U shape (length)		GZ, NW, WW, ASO.*			40	4000 K	BW	Batwing
		L(LxL)	L shape (length)	1200	1200 lm/ft - Maximum					NW	Narrow
										GZ	Graze
										ww	Wallwash
		Comes in 90	degree only.	Outputs between listed min and max are available. * 1000 lm/ft max. only for GZ, NW,WW and ASO.						Choose only o	ne of the options above

SPECIFY LENGTH FINISH		FINISH	,	VOLTAGE	DRIVER		CIRCUITS		MOUNTING		BA	BATTERY (OPT.)	
NL	nominal	W	white	120	120V	DP	dimming (0-10V) 1%	1	1 circuit	SB9	surface TB/TG 9/16	B(#)	battery pack
EX	exact	BLK	black*	277	277V			2	2 circuits	SB15	surface TB/TG 15/16		(integral)
		AP	aluminum	347	347V			+E(#)	emergency circuit*	SBS	surface screw slot t-bar		
			paint*	UNV	universal					S	surface drywall ceiling		
										sc	surface solid ceiling		
*Additional 5 working days required.						*Specify	quantity				m 5ft; ilable with 347V onsult factory		

• Refer to specification sheets for complete details. Note that only options shown above qualify for QuickShip+.

© 2016 Axis Lighting Inc. 1.800.263.2947


[T] 514.948.6272




# **How to Specify 90 degree Corners and Patterns**

# **Example**

### **Defining R - Rectangular shape**




#### **Defining L shape**




**Note:** The first number will always define the width, the second - the length.

### **Defining U shape**



**Note:** The first number will always define the right arm length, the second - the width, and the third the left arm length.

### **Defining S - Square shape**



Note: The number will define the width. (All sides are the same length).

• Refer to specification sheets for complete details. Note that only options shown above qualify for QuickShip+.

