


*** Please see page 2 for example on how to specify various right angle patterns.**

Project _____


Type _____

Notes _____



TB3DILEDPAT	R (11'X8')
PRODUCT ID	PATTERNS AND LENGTH

TOP VIEW - Rectangle Corner Pattern



TB3DILEDPAT	U (9'X11'X11')
PRODUCT ID	PATTERNS AND LENGTH

TOP VIEW - Open Shape Corner Pattern

IMPORTANT! – all corner patterns must be submitted with drawings indicating dimensions and angles degree.

Refer to axislighting.com for complete fixture details, IES files, and installation instructions



Ordering Guide

TB3DILEDPAT	PRODUCT ID	PATTERNS AND LENGTH (SELECT ONE)	LUMENS/FT INDIRECT	LUMENS/FT DIRECT	CRI	COLOUR TEMP.	SHIELDING INDIRECT
TB3DILEDPAT	Beam 3 Direct/Indirect	S(L) square shape (length) R(LxL) rectangular shape (length) U(LxLxL) U shape (length) L(LxL) L shape (length)	300 300 lm/ft - min 1200 1200 lm/ft - max	300 300 lm/ft - min 1000 1000 lm/ft - max for GZ, NW, WW, ASO.* 1100 1100 lm/ft - max	80 80 CRI	35 3500 K 30 3000 K 40 4000 K	SO spotless lens BW batwing
		Comes in 90 degree only.	Outputs between listed min and max are available.	Outputs between listed min and max are available. * 1000 lm/ft max. only for GZ, NW, WW and ASO.			

SHIELDING DIRECT	SPECIFY LENGTH	FINISH	VOLTAGE	DRIVER	CIRCUITS	MOUNTING/SUSPENSION
SO spotless lens ASO asymmetric BW batwing NW narrow GZ graze WW wallwash	NL nominal EX exact	W white BLK black* AP aluminum paint*	120 120V 277 277V 347 347V UNV universal	DP dimming (0-10V) 1%	1 1 circuit 2 2 circuits +E(#) emergency circuit*	CA(#) drywall+cable length (36" std.) CT9(#) TB/TG 9/16+cable length (36" std.) CT15(#) TB/TG15/16+cable length (36" std.) CTS(#) screw slot+cable length (36" std.) SA(#) drywall+stem length <48" (18" std.) CASL(#) drywall cable sloped ceiling SASL(#) drywall stem sloped ceiling
		*Additional 5 working days required.			*Specify quantity	See Mounting kit guide for full specification code. Specify quantity


BATTERY (OPT.)
B(#) battery pack 4' sections
Requires 120V or 277V Please consult factory

Refer to specification sheets for complete details. Note that only options shown above qualify for QuickShip+.


How to Specify 90 degree Corners and Patterns

Example

Defining R - Rectangular shape




Defining L shape




Note: The first number will always define the width, the second - the length.

Defining U shape



Note: The first number will always define the right arm length, the second - the width, and the third - the left arm length.

Defining S - Square shape



Note: The number will define the width. (All sides are the same length).

IMPORTANT – all corner patterns must be submitted with drawings indicating dimensions and angles degree.



A large grid of squares, intended for drawing corner patterns. The grid consists of 30 columns and 30 rows of squares, providing a space for technical drawings.